Home-Style Laundry Detergent Packs

CLASSIFICATION

Laundry Detergent Packs

PRODUCT DESCRIPTION

Home-Style Laundry Detergent Packs are an enzymatic detergent in pre-measured, water-soluble packs that are ideal for home-style machines. This product delivers effective stain removal against tough soils, helps to eliminate malodor in the first wash and retain freshness in linens. This product is ideal for Long Term Care or Facilities customers as it is easy to use, safe to handle, and helps eliminate waste and spilling. Effective in low and high temperature applications.

USE

FOR INSTITUTIONAL USE ONLY
DIRECTIONS FOR USE

1. Sort laundry in loads of similar color, fabric type and amount of soil.
2. Take the detergent pack out of the tub with dry hands and place it in the washer. Close tub after use.
3. Add one pack for small or medium loads to the empty washer. Add two packs for larger loads, heavy soils, or hard water conditions.
4. Place clothes inside the washer, on top of pack(s).
5. Select appropriate wash cycle and temperature according to the garment's fabric care label.

Consult your Ecolab Specialist or call 1-800-35 CLEAN (352-5326) for specific use directions, service, or additional information.

PHYSICAL & CHEMICAL PROPERTIES

Appearance: Powder
Color: Opaque, light blue
Odor: Perfume, fragrances
pH: 10.0 - 11.3, 1%

Ingredients:

Sodium carbonate	497-19-8
Zeolite	1318-02-1
Alcohols, C12-16, ethoxylated	68551-12-2
Water	7732-18-5
Precipitated silica	112926-00-8
Sodium polyacrylate	9003-04-7
Fragrance added	

%P: Formula ingredients contain no phosphorus

PACKAGING & PRODUCT NUMBERS

Size	Product Number
2 - 60 - 19.8 G (0.7 OZ)	**6101955**
450 – 19.8 G (0.7 OZ)	**6101956**

© 2019 Ecolab USA Inc • All rights reserved