

FLATWARE PRESOAK

ENZYME FORTIFIED SOAK FOR UTENSILS

Product Properties

COLOR: Green
ODOR: None
pH(1%) 9.7-11.0
FOAMING: Low
DETERGENCY: Excellent

Description

This product utilizes the latest ingredients that are less hazardous to the environment without sacrificing performance. This unique solid product provides effective and economical presoaking of kitchenware and cuts down wasted product. Our dual purpose product is also effective in detarnishing silver! Enzyme fortified to quickly soften the toughest food soils from kitchenware and flatware prior to mechanical washing. For use on flatware, silverware, pots, pans, utensils, and many other kitchen items. Safe on soft metals. Works in all water conditions. Does not contain phosphates or NTA. Container has an easy lift handle for placing jar into dispenser.

Features...Benefits

ConcentratedEconomical
Solid ProductConvenient Handling
Dispenser ControlledEconomical
Reduces RewashLabor Saving
VersatileEase of Use

Directions

This product should be dispensed only from equipment designed specifically to handle solid capsule detergents. Remove cap and place inverted capsule into bowl unit. Set the detergent timer to flush an adequate amount of water against block and flow into presoak tub/tray. For consistent feeding of product, it is suggested that cold or warm water is used to dissolve product. Typical usage is ½ to 1 ounce per 3 gallons of water. Fill the remainder of the soak pan with warm water. Place flatware into pan and allow to soak until soils have been loosened. For detarnishing, place a piece of aluminum foil to cover bottom surface of soaking tray. Rack flatware and rinse with water from sink to remove excess detergent, then wash as usual in mechanical washer. For pots and pans that require extra soaking, direct detergent solution into sink and fill with warm to hot water. Place pots and pans into sink and allow to soak until the soils can be easily removed.

Safety Information

FOR INSTITUTIONAL AND INDUSTRIAL USE ONLY. NOT FOR CONSUMER USE.

IF IN EYES: Immediately flush with running water for 15 minutes and get medical treatment.

IF ON SKIN: Immediately flush skin with running water. See physician if burns appear or irritation persists. Remove contaminated clothing and wash before reuse.

INGESTION: If swallowed, DO NOT induce vomiting. Rinse mouth and immediately drink 1-2 glasses of water or milk. Transport to an emergency center for immediate medical treatment.

Letter of guarantee available upon request.

**REFER TO PRODUCT LABEL AND SDS
FOR ADDITIONAL INFORMATION**

160525-0972
© INTERCON 2016



1100 Central Industrial Dr.
St. Louis, Missouri, 63110

toll free: 800 325 9218
main: 314 771 6600
fax: 314 771 6608

www.interconchemical.com

