
## Pole mount for Expanse sensors

Mount your XP20 sensor quickly and easily using the durable and flexible XP20 mount. With three axes of rotation and a slide-on sensor mounting feature, you'll have no trouble getting your XP20 to the angle and position you need.



- Three axes of rotation for getting the sensor into any necessary position and angle
- For even more flexibility, knuckles can be detached and reattached at a 90-degree angle
- Mount bolts can easily be loosened or tightened using a single wrench
- Attach the sensor quickly and easily by simply sliding it over the mounting tongue; for added stability, use the thumb screw to attach the sensor even more firmly
- Supports a 20-lb. (6.8-kg) load

- Rotating end piece means no rotating backplate is needed
- Heavy duty aluminum construction and powder coating make the mount sturdy and long-lasting
- Two contact points for attachment to circular or non-circular poles
- Accepts ¾" banding



# XP20 Mount technical specifications

### **Physical properties**

- Weight: 3 lbs. (1.36 kg)
- Dimensions: 8 in. × 15.5 in. × 3.625 in. (20.3 cm × 39.4 cm × 9.2 cm)
- Constructed of aluminum 0.1875 in. (0.48 cm) thick
- Powder coated
- Stainless steel hardware

### Mounting

- Rotational axes: 3
- Maximum recommended load at farthest point from pole: 20 lbs. (9.1 kg)
- Slotted for ¾-in. (1.9-cm) banding
- Contact points with pole: 2
- Easy slide-on sensor mounting, with thumb screw for added stability

#### Support

- Extended support options available; contact a Wavetronix representative for more information.
- Comprehensive user guide

#### Warranty

■ Five-year warranty against material and workmanship defect

# **Ordering information**

XP20 Mount 101-0457

XP20 36-inch Mount 101-0461

### Contact us

801.734.7200 sales@wavetronix.com www.wavetronix.com